



C:\WINDOWS\system32\cmd.exe

Microsoft Windows XP [Version 5.1.2600]

Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 60.0.0.10

Pinging 60.0.0.10 with 32 bytes of data:

Destination host unreachable.

Destination host unreachable.

Destination host unreachable.

Destination host unreachable.

Ping statistics for 60.0.0.10:

Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>_

Pinging 60.0.0.10 with 32 bytes of data:

Request timed out.

Request timed out.

Request timed out.

Request timed out.

Ping statistics for 60.0.0.10:

Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>_



C:\WINDOWS\system32\cmd.exe

<C> Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>route add 60.0.0.0 mask 255.0.0.0 50.0.0.1

C:\Documents and Settings\user>route print

=====

Interface List

0x1 MS TCP Loopback interface

0x2 ...50 fe 9c 09 4f 00 Intel(R) PRO/1000 MT Network Connection - Packe

Scheduler Miniport

=====

Active Routes:

Network	Destination	Netmask	Gateway	Interface	Metric
	50.0.0.0	255.0.0.0	50.0.0.10	50.0.0.10	10
	50.0.0.10	255.255.255.255	127.0.0.1	127.0.0.1	10
50.255.255.255	255.255.255.255	255.255.255.255	50.0.0.10	50.0.0.10	10
	60.0.0.0	255.0.0.0	50.0.0.1	50.0.0.10	1
	127.0.0.0	255.0.0.0	127.0.0.1	127.0.0.1	1
	224.0.0.0	240.0.0.0	50.0.0.10	50.0.0.10	10
255.255.255.255	255.255.255.255	255.255.255.255	50.0.0.10	50.0.0.10	1

=====

Persistent Routes:

None

C:\Documents and Settings\user>_



C:\WINDOWS\system32\cmd.exe

<C> Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>route add 50.0.0.0 mask 255.0.0.0 60.0.0.1

C:\Documents and Settings\user>route print

=====

Interface List

0x1 MS TCP Loopback interface

0x2 ...50 86 5f 09 50 00 Intel(R) PRO/1000 MT Network Connection - Packet Scheduler Miniport

=====

Active Routes:

Network	Destination	Netmask	Gateway	Interface	Metric
	50.0.0.0	255.0.0.0	60.0.0.1	60.0.0.10	1
	60.0.0.0	255.0.0.0	60.0.0.10	60.0.0.10	10
	60.0.0.10	255.255.255.255	127.0.0.1	127.0.0.1	10
	60.255.255.255	255.255.255.255	60.0.0.10	60.0.0.10	10
	127.0.0.0	255.0.0.0	127.0.0.1	127.0.0.1	1
	224.0.0.0	240.0.0.0	60.0.0.10	60.0.0.10	10
	255.255.255.255	255.255.255.255	60.0.0.10	60.0.0.10	1

=====

Persistent Routes:

None

C:\Documents and Settings\user>

C:\Documents and Settings\user>route delete 50.0.0.0

C:\Documents and Settings\user>route print

=====

Interface List

0x1 MS TCP Loopback interface
0x2 ...50 86 5f 09 50 00 Intel(R) PRO/1000 MT Network Connection - Packet Scheduler Miniport

=====

Active Routes:

Network	Destination	Netmask	Gateway	Interface	Metric
	0.0.0.0	0.0.0.0	60.0.0.1	60.0.0.10	10
	60.0.0.0	255.0.0.0	60.0.0.10	60.0.0.10	10
	60.0.0.10	255.255.255.255	127.0.0.1	127.0.0.1	10
60.255.255.255	255.255.255.255		60.0.0.10	60.0.0.10	10
	127.0.0.0	255.0.0.0	127.0.0.1	127.0.0.1	1
	224.0.0.0	240.0.0.0	60.0.0.10	60.0.0.10	10
255.255.255.255	255.255.255.255		60.0.0.10	60.0.0.10	1

Default Gateway: 60.0.0.1

=====

Persistent Routes:

None

C:\Documents and Settings\user>

=====

Active Routes:

Network	Destination	Netmask	Gateway	Interface	Metric
	0.0.0.0	0.0.0.0	50.0.0.1	50.0.0.10	10
	50.0.0.0	255.0.0.0	50.0.0.10	50.0.0.10	10
	50.0.0.10	255.255.255.255	127.0.0.1	127.0.0.1	10
	50.255.255.255	255.255.255.255	50.0.0.10	50.0.0.10	10
	127.0.0.0	255.0.0.0	127.0.0.1	127.0.0.1	1
	224.0.0.0	240.0.0.0	50.0.0.10	50.0.0.10	10
	255.255.255.255	255.255.255.255	50.0.0.10	50.0.0.10	1

Default Gateway: 50.0.0.1

=====

Persistent Routes:

None

Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 60.0.0.10

Pinging 60.0.0.10 with 32 bytes of data:

Reply from 60.0.0.10: bytes=32 time=3ms TTL=127
Reply from 60.0.0.10: bytes=32 time=1ms TTL=127
Reply from 60.0.0.10: bytes=32 time=1ms TTL=127
Reply from 60.0.0.10: bytes=32 time=1ms TTL=127

Ping statistics for 60.0.0.10:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 1ms, Maximum = 3ms, Average = 1ms

C:\Documents and Settings\user>_

Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 50.0.0.10

Pinging 50.0.0.10 with 32 bytes of data:

Reply from 50.0.0.10: bytes=32 time=1ms TTL=127
Reply from 50.0.0.10: bytes=32 time=1ms TTL=127
Reply from 50.0.0.10: bytes=32 time=1ms TTL=127
Reply from 50.0.0.10: bytes=32 time=1ms TTL=127

Ping statistics for 50.0.0.10:

 Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
 Minimum = 1ms, Maximum = 1ms, Average = 1ms

C:\Documents and Settings\user>_